Hisense

http://www.hisense.com

Hisense® Active 3D Glasses

User's Manual



Model: FPS3D02

Please read this manual carefully before using the glasses and keep the manual in a safe place.

Dear customers:

Thanks for choosing Hisense® . We believe this product when used correctly will provide you with a joyful experience. Please read this user's manual before using and keep in a safe place, Hisense® shall not be liable for any or held responsible for any misuse for failing to follow the guideline in the manual.

Product Overview

The active 3D glasses included in this package are used for Hisense® 3D television only. Hisense® active 3D glasses, integrating the advanced LCD shutter technology with anti-interference IR communication, will bring you a vivid and wonderful 3D experience.

Package Contents

1. Active 3D Glasses x1
2. USB Charge Cable x1
3. Interchangeable Nosepiece x2 (Two nosepieces for replacing , greatly enhance the comfort of wearing)
4. Storage Pouch x1
5. Cleaning Cloth x1
6. User's Guide(Warranty Card) x1
7. Certification of Approval x1

Product Features



1. Liquid Crystal Lenses

The fast response, high transmittance and contrast LCD lenses are subject to scratching please avoid any external force when using or when storing.

2. IR Signal Receiver
When watching TV in 3D, It is recommend to face toward the direction of the emitter which is built into the TV for a better viewing experience.

3. LED Indicator
Power ON: green LED is on for 1.5 seconds;
Power OFF: green LED blinks three times;
Low Battery: green LED blinks once every second;
In Charging: red LED is on;
Full Charged: red LED goes out;

4. Power Button
Turn ON: Press the button once;
Turn OFF: Hold the button for about 1.5 seconds.

5. Earpieces
Compact design, Folding earpieces.

6. Mini-USB Charge Port Cover
Keep the cover closed to prevent dust go inside.

7. Mini-USB Charge Port
Charge the glasses by connecting your glasses to USB port of your TV or computer.

Specifications

Active 3D glasses			
Shutters	Liquid Crystal	Glasses Weight	39g
Power supply of 3D glasses	Rechargeable Li-polymer Battery	SYNC Operation	IR
Charging Period	A full charge needs about 4 hours		
Battery Operating Life	up to 30 hours of usage with one full charge		
Working Condition	Working Temperature	0~40°C	
	Storage Temperature	-5~50°C	

Charging Your Glasses

We recommend you charge your 3D glasses as soon as the low battery indicator is lit ensuring your watching times in 3D effect is optimised. You can charge your glasses by connecting them via USB cable supplied directly to the USB port on your TV or computer.

Tips

The glasses will automatically turn off to save power in the following condition:

1. When the glasses are turned on, the glasses will enter standby mode for 1.5 minutes if no 3D sync signal received. the glasses will turn in to working mode once the glasses receive the 3D sync signal during standby mode, otherwise, the glasses will automatically turn off with the green LED indicator blinking three times.

2. If the glasses become disconnected with the emitter because of incorrect distance and or angle, they will automatically work for a period of 5 seconds. The glasses will resume working once a 3D sync signal is received, otherwise, the glasses will enter into standby mode(for 1.5 minutes).

3. If you change the channel or input while watching 3D content, the glasses will automatically work for a period of 5 seconds. the glasses will resume working once 3D sync signal is received, otherwise, the glasses will enter into standby mode(for 1.5 minutes).

Troubleshooting

Q1: What can I do if there is no 3D effect after I have put on and turned on the glasses?

Try this:

1. Make sure you are watching in 3D sync signal covered area .
2. Check the battery volume of your glasses, please charge if low in power
3. Please check if the TV setup is in 3D mode or not.

Q2: Why do the lenses blink when watching 3D films?

Try this:

1. Please charge the glasses immediately if the battery is seriously low.
2. Interference such as magnetic fluorescent lamps (50 or 60Hz) may cause flickers, please turn off interference source if this occurs.

Caution

1. The 3D glasses are used for 3D content viewing only. Do not use them for general eye wear purpose, such as sunglasses and general eye wear, Doing so may result in injury.
2. The glasses are powered by a rechargeable lithium-polymer battery, please charge the glasses with a standard 5V USB connection
3. Do not place the glasses in a location exposed to direct sunlight, heat, fire or water. this may result in product malfunction or fire.
4. Clean the 3D glasses with a clean, lint free, dry, soft cloth. Any chemical cleaning agent spray on the 3D glasses may damage the product surface or cause product malfunction.
5. Do not apply force to the 3D glasses. Dropping or bending may damage the product.
6. When watching a 3D video, do not place anything fragile nearby. Involuntary movement or surprised reaction may occur as a result of certain 3D content which result in surrounding objects being broken or hurt yourself.
7. Please watch 3D content in IR signal covered area, and make sure no objection is placed close to the front of IR emitter.
8. 50Hz or 60Hz magnetic fluorescent lamp may cause flicker to your 3D glasses.Turn off the lamp if this happens.
9. Do not use the 3D glasses if there are any wire exposed or cracks to the lens.
10. For comfort, replaceable nosepieces are applied to the glasses. Please place the nosepieces out of children's reach to prevent children swallowing the nosepieces. Children must use the glasses under their parents' supervision.

Warning

1. We recommend pregnant women, people with heart disease or epilepsy and people who are easily nauseous should not watch 3D content.
2. Due to the stereoscopic effects and the uncompleted visual development of younger children under 3 years of age we recommend you not allow them to watch 3D content. Long time watching may affect there visual development.
3. Watching 3D content for a long time may cause headache or eyestrain to you, please stop watching if you have any uncomfortable feeling and take a rest immediately. Please consult a doctor if the feeling do not release.
4. Some individuals may experience seizure or other complications when exposed to certain visual images, including flashing lights or patterns that may appear in a video or games. If you or any of your relatives have a history of seizures or epilepsy, consult a doctor before watching.

Warranty Card

Terms of Warranty

1. Please attach your purchase invoice on the upper-left corner of the card and reserve it carefully

2. Service policies:
   (1). Our company strictly enforces the regulations of the laws of the "Product Quality Standard "and "Consumer Protection Law " .
   (2). The period of free warranty for the product is one year(date from the day of purchase.)

3. Warranty will be voided under the following circumstances.
   (1). Without providing copy of a valid purchase invoice showing a purchase date.
   (2). The invoice or warranty card has been changed or the bar code is different from that on the active 3D glasses.
   (3). Damage caused by customer inappropriate usage, maintainpnce or preservation.
   (4). The breakdown and damage is caused by the force majeure.
   (5). Damage caused by misuse and or altered by a non preferred authorised service agent.

4. You may be required to have your glasses sent to an authorised service centre to validate your warranty on inspection. Please call 1800 447 367 for further instructions.

Warranty Card

Feedback Couplet

Product model No.	
Date of purchase	
Purchase store	
Purchasing invoice No.	
Customer signature	
Customer phone	
Customer address	